




Five Star Mfg.
722 Central Ave. P.O. Box 636
Springfield, Tn 37172
1-888-872-7278 FAX 1-800-793-4806



Installation Procedures for Dodge Sprinter 2500 with 3.0 Diesel

**It is necessary to use Kat's Circulating Tank Heater part # 13150 for this Application.*

Drain the cooling system. Then cut the lower radiator hose in the middle of the hose and install the 1 ½" T - style Adapter (Kat's part # 28115, must be purchased separately) into the lower hose and secure with two hose clamps. Locate heater hose along right side bank of engine. Cut 4" out of the center of hose and install the "Y Connector" (Kat's part # 28110) with two hose clamps. Mount tank bracket to sheet metal plate along right side wheel well. Mount as low and close to frame as possible. Mount heater tank in tank bracket and secure. Attach 5/8" green stripe heater hose from lower radiator hose to lower connection on heater tank and secure with hose clamps. Attach 5/8" green stripe heater hose from "Y connector" to upper connection of heater tank and secure with hose clamps. Attach electrical plug to grille and fasten with wire ties. Fill system with coolant and pressure test for leaks.